



S.NO.	DESCRIPTION	TAG NO.
1	BACK PRESSURE REGULATING VALVE	BPRV
2	PRESSURE CONTROL VALVE	PCV
3	PRESSURE GAUGE	PG
4	PRESSURE SWITCH - LOW	PS-L
5	PRESSURE SWITCH - HIGH	PS-H
6	SOLENOID VALVE	SV
7	ROTA METER	R
8	ISOLATING VALVE	IV

\* Inlet Piping (To PCV-Common) & Exhaust piping (From BPRV - A&B), Cabling, Glands, ML TANK, I.V-7 & IV-8 are not in our Scope of Supply.

\* Isolation Valves should be Needle Valves or any other gradually opening valves.

JOFLO SCOPE OF SUPPLY				
S.NO	DESCRIPTION	QTY.	INLET PRESSURE	OUTLET PRESSURE
1	PCV-COMMON	1	3 Kg/cm <sup>2</sup>	1 Kg/cm <sup>2</sup>
2	PCV-B	1	1 Kg/cm <sup>2</sup>	15mbar
3	PCV-C	1	1 Kg/cm <sup>2</sup>	30mbar
4	BPRV-A	1	30mbar	Atm
5	BPRV-B	1	50mbar	Atm
6	PS - H (FLAME PROOF)	1		
7	PS - L (FLAME PROOF)	1		
8	PRESSURE GAUGE	4		
9	SOLENOID VALVE	2		
10	ROTAMETER	2		
11	ISOLATION VALVE	6		